

Installation Guide

Industrial\commercial

Roof

Metal

New

Contractor - Ready

Step 1:

It is recommended to use the roof sheet as a ramp. First roof sheet is used, before installing Polynum. Just remember NOT to screw in the first roof sheet, which shall be lifted later on for the last (first) layer of Polynum.

Step 2:

Laying metal strips. Metal strips are made of GI or Zinc alum metal. Metal strips are recommended when having exposed ceiling. Although Polynum does not require support (as being light weight and self-supported product), metal strips add aesthetic and lean finish. Metals strips can be skipped when using ceiling (false or drop ceiling)

Step 3:

Lift Polynum rolls to the roof area, and place them at the side frame. Prepare the rolls to unroll them across the purlins.

Step 4:

Start laying Polynum insulation. If using Self Adhesive, pulling the S/A strip will be done ONLY when the second layer of Polynum is applied. Overlapping shall be minimum 50mm for best performances.

Step 5:

Applying Polynum all weather heavy-duty closing Tape (50mm or 75 mm width) to secure overlapping (joints).

